


Printer Combo Adapter

QUICK START GUIDE

VERSION 1.1



© All rights reserved.

All trade names are registered trademarks of respective manufacturers listed.

The Bluetooth name and the Bluetooth trademarks are owned by Bluetooth SIG, Inc.

This manual may not be copied in any media or form without the written consent of original maker.

1

Check your package, there are printer combo adapter, Power adapter, Utility CD and this Quick Start Guide.



Printer
Combo Adapter



Power Adapter




Utility CD



Manual

2

Check your PC, there must be a Bluetooth USB dongle plus Widcomm or Windows XP Bluetooth driver installed. If there is NOT, you shall purchase one. and install the driver.



3

Connect the adapter to parallel port of your printer.

OR

Connect one end of USB cable to the adapter, and connect another end to USB port of your printer.



4

Power on your printer, wait until it is ready.

5

Apply power to the adapter by using the accompanied power adapter.

1. Power LED will be on.
2. Bluetooth LED will be blinking once a second.

6


Power on your PC, follow the steps mentioned in next four pages to :


1. Find your combo printer adapter device.
2. Add a printer driver to work with this device.
3. Start your normal printing.

MY BLUETOOTH PLACES


Step 1:

Method 1:

Double click  on your desktop.
Click Folder on the toolbar.
Folder window will appear on left side of your screen.



Method 2:


Right click  on the lower right hand corner of your screen.
Select **Explore My Bluetooth Places**.



Two folders appear on the window.


They are:

Entire Bluetooth Neighborhood
and My Device.




Step 2:

Click **Entire Bluetooth Neighborhood** to search for devices available to you. Once Bluetooth devices are detected, their icons together with device names will be displayed on the screen.




You also may start a search for devices by clicking **Bluetooth** from the toolbar.



Step 3:

In this example, One Bluetooth printer device is found in your Bluetooth neighborhood.



Step 4:

Right click on your device icon
Select **Pair Device** .




Step 5:

Enter Bluetooth security code
0000 and press **OK**.



Step 6:

The pairing process is now complete.




This is the service we want to know. We will look at it later. The “My Bluetooth Places” program provides an easy way to find different application services through Bluetooth connections. A variety of Bluetooth services and explanations can be found in the “Help” file of the “My Bluetooth Places” program.

ADD LOCAL PRINTER

In the following example, we assume a printer combo adapter (with series#: BT-PTR-B0A251) is connected to an EPSON Stylus C61 printer.


Step 1:

From MY BLUETOOTH PLACES, Right click on printer combo adapter folder (with series#: BT-PTR-B0A251), then select OK to install a printer driver for it.



Step 2:


Add Printer Wizard will show up, find the brand name and model number of the printer driver you want this printer adapter to use. It will ask you to install the printer driver if it has not been installed in your system before. If the driver has been installed, Add Printer Wizard will pass very quickly. In this example, we select EPSON Stylus C61 as the printer, supposed its driver was installed before, so just click OK to continue.



Step 3:


You can assign a name such as EPSON Stylus C61 Series to the printer combo adapter just selected. In end user side, you will only find a printer named EPSON Stylus C61 Series you will not see any printer named BT-PTR-B0A251.

Click OK to complete the installation.



START PRINTING


Click **My Computer** icon on the desktop screen, select **Control Panel**, select **Printers and Faxes**, then you can find a Bluetooth Printer is there:
EPSON Stylus C61 Series.



Print a file by using combo printer adapter is quite straightforward, it is just like the normal way you are printing a file.

For EPSON Stylus C61 Series:

When page range and number of copies screen prompts, select **EPSON Stylus C61 Series** printer, then click OK.



EPSON Stylus C61 Series